

SPECIFICATIONS / SPECIFIKATIONER / SPESIFIKASJONER / TEKNISET TIEDOT

Battery / Batteri: / Akku: CR2032 3V

Voltage / Spænding/ Spenning / Spänning / Jännite: 3V


Replace battery. Remove cover by pressing on release button on the bottom of the rear light. Need to use some force.



Insert battery.



Attach light again on the top and press in at the bottom until you hear a clicking sound.



WARNING: Keep batteries out of reach of toddlers and small children because of the risk of ingestion, which may result in potentially fatal internal damage, or choking.

If battery leakage with skin wash with soap thoroughly. In case of eye contact, see medical attention immediately.

WARNING: Remember to use the + and – terminals correctly. Never mix new and used batteries together or mix different battery brands together. If the electrical product is not used over an extended period, the batteries should be removed from the product. Do not short-circuit, disassemble, charge, and keep the batteries away from open flames. Do not charge none-rechargeable batteries.